

Electrical Service Order – If you need electricity, you must complete and return this form along with your vendor application. No on-site electricity orders are permitted.

Vendor Name: \_\_\_\_\_

Contact Person: \_\_\_\_\_

Phone Number: \_\_\_\_\_ Email: \_\_\_\_\_

Check appropriate box below:

Electrical Service	120 Volt	Single Phase		
Amps	Watts	Maximum HP	Connector Type	Cost
0-5	1-600	0-1/3 hp	1	complimentary
6-15	601-1800	1/2-1 hp	1	\$35
16-24	1801-2880	1-1/2 hp	2	\$55
25-30	2881-3660	1-1/2 – 2 hp	2	\$75
31-50	3601-6000	2-3 hp	3	\$100

Electrical Service	120/208 Volt	Single Phase		
Amps	Watts	Maximum HP	ConnectorType	Cost
0-5	1-1040	0-1/2 hp	2	\$50
6-15	1041-3120	1/2-1-1/2 hp	2	\$75
16-24	3121-4992	1-1/2 – 2-1/2	2	\$100
25-30	4993-6240	2-1/2 – 3 hp	2	\$150
31-50	6241-10400	3-5 hp	3	\$200

Note: Please Check Your Equipment and Electrical Motor Specs Very Carefully!

1. Applicant is responsible for providing the correct “Connector Type” for the desired from the tables above. See diagrams for approved “connector types.”
2. Connector Type #1 = standard polarized 3-spade 120-volt single-phase connector for use on 120 volt services of 15 amps or less.
3. Connector Type # 2 = standard 120/208 volt connector that is to be used for all 120 volt single phase and 120/208 volt three phase services of 1-30 amps. Connector Type is #L2130. Single Phase 120-volt: Connect the “hot leg” [black] to “X” spade: connect neutral [white]to neutral spade: connect ground [green] to ground spade. Single Phase 120/208- volt: Connect “hot leg” [black] to “X” spade, connect “hot leg” [red] to “Z” spade, connect neutral [white] to neutral spade, connect ground [green] to ground spade. Three Phase 120/208 volt: Connect “hot leg”[black] to “X” spade, connect “hot leg” [red] to “Z” spade, connect “hot leg” [blue] to “Y” spade, connect neutral [white] to neutral spade, connect ground [green] to ground spade.
4. Connector Type #3 = special connection for all services greater then 30 amps. Our “staff electrician” will make connections.
5. Management not responsible for lost sales due to power outage.
6. Upon arrival to the event, check in with management to secure a time for the electrician to install your service.

